

window modes

INSTALLATION MANUAL

Blidspace Bracket 100 for
Lutron 100, 150 and 300 Motors
Installed in S130x130 Pocket

window modes

Installation Manual
Blindspace Bracket 100

What's In The Box



Blindspace Bracket 100 shown with two halves already assembled. Four (4) total pieces in box.
Also includes four (4) set screws.

Blindspace Bracket 100 is designed for Lutron Roller Shade Series 100, 150 and 130.

No Drilling Required.

Use the following steps for bracket installation.

1.



Slide the 2 piece bracket into the Blindspace 130x130 pocket. The long "leg" of the bracket should be closest to the outer edge of pocket when installed.

2.



3.



Once bracket is swiveled into pocket, the bracket can slide along pocket for final adjustment. & Tighten Two Set Screws

4.



Add Lutron Bracket and use set screw to secure in place.
Screw Driver Needed.

5.



The Blindspace bracket and Lutron bracket are now set in place for final shade installation.